

Read these instructions carefully!
ENGLISH INSTRUCTIONS FOR USE



shizil®
Rope slider

No Personal Protection Equipment!

WARNING! PRODUCT IS NOT TESTED ON LIMIT LOAD

The Rope Slider may only be used in a climbing system by those who are skilled in the use of climbing equipment or supervised by an instructor.

shizil®

Postbus 578
4100 AN Culemborg
The Netherlands

+31 (0)6 193 409 05
www.shizil.com
info@shizil.com

 You can find us on
facebook.com/Shizil

HOW TO USE THE ROPE SLIDER

The Rope Slider can be used as a prusiklift both for a short and a main anchor. (Figure A and B)

Rope Slider


Weight: 28 gram

Ø A: 24 mm

Ø B: 14 mm

Material: hot forged aluminum 6061T6

Finish: anodised



Explanation of the print

shizil® Rope slider is a product of the brand **shizil®**, part of Betuwe Boomverzorging.

No PPE!: No Personal Protection Equipment!

For security reasons it is not allowed to use the Rope Slider as a bearing part of a climbing system or other application.

Serial Number: The serial number consists of the letter R, followed by a unique production number.



A. Short anchor / lanyard



B. Main anchor

WARNINGS

Use the Rope Slider only as an aid in a climbing system or other nonbearing application.

It is not allowed in any way to apply force on both rings of the Rope Slider simultaneously. (Figure C)

Make sure that the Rope Slider is always in the middle of the upper side of the carabiner and remains there so it can never affect or damage the functioning of the lock of the carabiner. (Figure D)

The Rope Slider should only be used by persons who are capable and skilled in dealing with climbing equipment as used in tree care and mountaineering.

If the Rope Slider is damaged in any way or for any reason whatsoever it is not permitted to use it anymore on account of the serious damage it can cause to (climbing) lines and other climbing material.

In case of illegibility of the inscription "No PPE!" it is also no longer allowed to use the Rope Slider.

shizil® is not responsible for any use other than as specified in this manual.

When in doubt about safe use of the Rope Slider please contact us.

KEEP THIS USER'S MANUAL

C. Do not apply force on both rings simultaneously!



D. Instructions for use

